# Qosium Trial Edition Install Guide

Trying out Qosium yourself gives the best guarantee that the software is suitable for your use case. This guide will walk you through the process of downloading and installing the Trial Edition of Qosium, which takes less than 15 minutes.

# Table of Contents

1. Create a Kaitotek Account	3
2. Sign In & Download Installer	7
3. Install Qosium Trial Edition on Windows	10
4. Install Qosium Trial Edition on Ubuntu	17
4.1. Qosium Probe Installation	17
4.2. Launching Qosium Probe	17
4.2.1. Manual Start	17
4.2.2. Qosium Probe Installed as Service	18
4.3. Qosium Scope Installation	18
4.4. Launching Qosium Scope	18
4.5. Uninstallation of Qosium Probe and Qosium Scope	19

# 1. Create a Kaitotek Account

To download Qosium Trial Edition, you'll need to create an account on our site. Please head to <u>the sign-up</u> <u>page</u> and fill out the sign-up form. Type your email address and company name first. Then, there is a little challenge, whose purpose is to hinder bots from creating accounts. Please read carefully the instructions and then answer the question below.

Sign Up for Free Trial	
Register an account for downloading and testing Oosium Trial Edition	
Please fill in the fields below to sign up. After filling out the form you will receive an email with	
instructions on how to proceed with downloading Qosium Trial Edition.	
Please notice that Qosium Trial Edition contains tools only for manual measurements. If you are interested in automatic monitoring, please contact Kaitotek support directly.	
Having trouble signing up? See our guide for help.	
Email address *	
first.last@mycompany.com	
Organization name *	
My Company Ltd.	
To prevent system misuse, let's make a simple check. Please read the following question carefully and answer in the field below.	
Calculate all the instances of the letter u in the headline of this form. Add that to the number you get from the box below. Read the instructions on the cover of the box.	
To open, bring the mouse cursor over me.	
Look inside and take the blue number.	
What is the number you get?	
Submit 🖨 Back	
we nancie your data with care. Please take a rew moments to read our privacy policy. Any information sent via forms is subject to the privacy policy.	

If you do not wish to disclose the company you are working for, type "Private". You'll need to input a valid email address, but you may also use an off-work email address, such as your personal Gmail.

After filling out the fields, press Submit. A following confirmation window appears if everything went

#### smoothly

You Have Mail	
We have sent a welcome mail to the given email address. Please check your mailbox and follow the instructions there.	
If the email doesn't arrive in a few minutes, please check your email junk folder. You can also contact our support support@kaitotek.com for assistance.	
You may close this page now. Thank you!	
Back to the main page	

If the window looks distinctly different, you might have failed to fill the fields correctly. In that case, please try again.

Next, open your mailbox. A welcome email should have arrived, which gives an overview of your new account.

If the email didn't arrive, refresh your mailbox. Check the junk mail folder as well since some email servers may classify automated emails as spam. If you didn't receive an email, please contact support@kaitotek.com for assistance.



Press **Set Password**, which takes you to the password reset page. Here you may create a password for your account. Be sure to use a unique, strong password with at least 8 characters. Type the password twice and then press **Change**.

Res	et acco	unt password
New password		
•••••		
Repeat password	ł	
•••••		
Change	ţ	ENG FIN

# 2. Sign In & Download Installer

After creating the password successfully, you'll be redirected to <u>the Sign In page</u>. Type in your email address and the freshly created password, and then press **Sign In**.

Sign In to Your I	Kaitotek Account
Password changed success below by using the new pas	fully. You may now sign in ssword.
Email address	
first.last@mycompany.com	
Password	
•••••	
Sign in	ENG FIN
Forgot password?	No account? Sign up now!

After signing in, you will be redirected to your account page. Continue to the <u>Downloads page</u> either from the top menu or from the account shortcuts.



Before downloading Qosium products, you'll have to accept the End-User License Agreement (EULA). Follow the instructions for reading the EULA, then click **Agree and Continue**.

## Kaitotek End-User License Agreement

Kaitotek products are proprietary software, and thus the usage is controlled by End-User License Agreement (EULA). Please take some time to read and familiarize yourself with the liberties and restrictions of the license.

For opening the document, a PDF reader software is needed, such as Adobe Acrobat Reader. If you have any questions or concerns regarding the EULA, contact us at support@kaitotek.com.

Click here to download Qosium End-User License Agreement

If you agree to the terms and conditions, click Agree and Continue to proceed to downloads.

Agree and Continue  $\rightarrow$ 

The downloads page lists one product package called *Trial Edition*, which contains Qosium Trial Editions listed operating systems. Locate the installer with your preferred operating system and press **Download**. For Windows, a single installer is available, while for Ubuntu you'll need to download Qosium Probe and Scope separately.

		Download Product Packages		
Free Trial				
		Installation package: Qosium Probe	Download	
	abanca			
		Installation package: Qosium Scope	Download	
×.	ubuntu®			
	I Windows 8	Installation package: Qosium	Download	
×	Windows 10			

# 3. Install Qosium Trial Edition on Windows

Before launching the installer, you'll need to install a **packet capture library** if you intend to run Probe in this machine. Follow our guide on installing a packet capture library on Windows.

It is highly recommended to install a packet capture library before proceeding to install Qosium. The Qosium installer provides some automated configuration for packet capturing, but installing a packet capture library afterward can invalidate these configurations.

After completing the packet capture library installation, locate and launch the Qosium Trial Edition installer file that you downloaded. After launching, proceed by clicking **Yes** on Windows *User Account Control* permission prompt.

User Account Control	×	(
Do you want to allow th changes to your device	nis app to make ?	
Qosium_installation_Win64_int_TRIAL_EDITI ON_20210419.exe		
Verified publisher: Kaitotek Oy File origin: Hard drive on this computer		
Show more details		
Yes	No	

On the first page of the installer, click **Next** to proceed.



The installer prompts you to accept the End User License Agreement (EULA). If you haven't yet read the EULA, please take a few minutes to read it thoroughly. Then check *I accept the terms of the license agreement* and click **Next** to proceed.



In the next step, you may change the installation directory for Qosium.



The next step considers the Start Menu shortcuts. It is recommended to leave the settings to default.



During the next step, Qosium will be installed in your system. After the installation process has been completed, you'll be prompted to automatically set your computer system clock synchronization parameters to optimal settings. If you hadn't installed Qosium to this computer before or adjusted any synchronization settings before, it is recommended to select *Set all for me*. Then click **Finish**.



If you selected Set all for me, the installer updates your system with optimal values.



Your installation is now complete. You can find the freshly installed Qosium in the start menu:



Use *Qosium Probe (desktop app)* to launch Probe in a command prompt window. Alternatively, select *Start Qosium Probe* service to set the Probe as an active Windows service. In that way, Qosium Probe is always in the background and starts with your device. To stop it, select *Stop Qosium Probe service*. To remove it from the Windows' service list, select *Remove Qosium Probe service*.

Launch Scope by selecting **Qosium Scope** from shortcuts. More launch options for Scope can be found <u>here</u>.

## 4. Install Qosium Trial Edition on Ubuntu

Qosium Probe and Scope are delivered as a deb software package, which can be installed with both *dpkg* and *apt*.

## 4.1. Qosium Probe Installation

To install a fresh or upgrade an existing Qosium Probe in a machine, open Terminal and run:

```
sudo dpkg -i QosiumProbe_<version_details>.deb
```

It is also possible to use *apt* and *apt-get* for the installation. These methods also install all dependencies automatically. Qosium Probe has only one external dependency, namely libpcap. Ubuntu typically comes with that library, but if you have made big changes to the operating system libraries and content, it may be useful to use, e.g., *apt-get*, when the installation happens the following way:

sudo apt-get install ./QosiumProbe\_<version\_details>.deb

The installation process asks all the relevant details, e.g., whether or not to install Qosium Probe as a Systemd service, etc.

## 4.2. Launching Qosium Probe

## 4.2.1. Manual Start

Run the following command in terminal (use *sudo* in front of the command if you don't have *superuser* privileges):

/opt/QosiumProbe/bin/QosiumProbe

Probe can be set in the background by pressing *Ctrl-Z* and typing bg, or adding & to the end of the command line.

If you installed Qosium Probe to be a background service, you might have Probe running already, and Probe won't start. You cannot, and don't need to, have more than one Qosium Probe instance per machine.

#### 4.2.2. Qosium Probe Installed as Service

If you installed Qosium Probe as a Systemd service, controlling of Qosium Probe happens with *systemctl* commands. Qosium Probe is launched automatically upon installation and device startup. Omit *sudo* from the commands below if you are *superuser* or sudo is not supported by the operating system.

Start:

sudo systemctl start QosiumProbe

Stop:

sudo systemctl stop QosiumProbe

**Request status:** 

sudo systemctl status QosiumProbe

Disable Qosium Probe from starting automatically upon reboot:

sudo systemctl disable QosiumProbe

Enable Qosium Probe to start automatically upon reboot:

sudo systemctl enable QosiumProbe

## 4.3. Qosium Scope Installation

To install Qosium Scope, open terminal and run

sudo dpkg -i QosiumScope\_<version\_details>.deb

Similarly to Qosium Probe installation, you can also use *apt* and *apt-get* to install the Qosium Scope from the deb package.

#### 4.4. Launching Qosium Scope

After installation, Scope can be launched by executing the following command in the terminal:

/opt/QosiumScope/bin/QosiumScope

(i) Qosium Scope does not require superuser privileges.

## 4.5. Uninstallation of Qosium Probe and Qosium Scope

To remove Qosium Probe from the machine, run:

sudo dpkg -r qosiumprobe

To remove Qosium Scope from the machine, run:

sudo dpkg -r qosiumscope